

1. Set the Power Switch to top position.

2. Place Lighttalk close on the left side of the pictures or letters.

3. Press and hold the Scan Button.
Scanning Sensor starts to blink in about 3 seconds, then starts scanning.

4. Scan by slowly running down along the pictures or letters till the end.
*)Do not lift Lighttalk from the paper while scanning.

5. Release the Scan Button when finished.
Indicator Light will blink 3 times.
*)Do not turn off the power while Indicator Light is blinking(Storing images).

Place Lighttalk close on this position.

Press and hold the Scan Button

Release the Scan Button

Scan the picture slowly at the speed of one second per a section.

1. Set the Power Switch to top position.

2. Place Lighttalk close on the left side of the pictures or letters.

3. Press and hold the Scan Button.
Scanning Sensor starts to blink in about 3 seconds, then starts scanning.

4. Scan by slowly running down along the pictures or letters till the end.
*)Do not lift Lighttalk from the paper while scanning.

5. Release the Scan Button when finished.
Indicator Light will blink 3 times.
*)Do not turn off the power while Indicator Light is blinking(Storing images).

Place Lighttalk close on this position.

Press and hold the Scan Button

Release the Scan Button

Scan the picture slowly at the speed of one second per a section.